

# FANUC PC Software

## Download of Software & Activation

### Instruction manual

# Purpose of this manual

## <Purpose>

This manual explains the follows:

- Procedure for software download.
- Procedure for software activation.

# I . Overview

This part explains overview of PC software delivery.

1. PC software delivery
2. Overview diagram of PC software delivery
3. Advance preparation
4. Procedure for software activation

# 1. PC software delivery

The conventional delivery method of PC software has been changed to distribution via FANUC America Customer Portal site.


The conventional delivery method of PC software:

- Software was provided to the customer by DVD.      Software DVD
- USB Hardware-key was used for activation.      Hardware-key(USB dongle)



What is "PC software delivery"?

- Software is delivered by FANUC America Customer Portal.
- Activation by Internet instead of the conventional USB hardware-key.




What is advantage of PC software delivery?

- Shorter delivery time.
- Computers without DVD drives or without the USB interfaces that can use used.

## 2. Overview diagram of PC software delivery

You can user software by the following steps from (1) to (10).



(\*) This computer can access the Internet. The computer without Internet can use the software, too.

(11) Start using software


### 3. Advance preparation (1/3)

Before you can download the software from FANUC Customer portal, please prepare the following.

#### 1. Prepare Windows computer (\*) with Internet access.

This manual expresses the computer, whether the computer can access the Internet or not such as the following.

- Computer with Internet access: Online PC
- Computer without Internet access: Offline PC



#### 2. Install Google Chrome browser to above Online PC.

Use Google Chrome to access the software delivery server and the license server.

#### 3. Allow receiving Emails from FANUC

After ordering the software an email is sent to you with following content:


- (1) Order details
  - (2) Instructions how to download the software
  - (3) Notification of license ticket (Information for activating software)
- Please keep a copy of all e-mail notifications for your records.**

### 3. Advance preparation (2/3)

#### 4. Check the access to FANUC America Customer Portal.


If you have not yet registered at FANUC America Customer Portal, please register:  
<https://myportal.fanucamerica.com/>

It is required that the account be a "CNC Portal Account".



#### 5. Check the access to the license server (\*).

Please check access to following URL  
<https://lc.codemeter.com/91943/depot/>



(\*) About accessing the Internet, please contact to your Network Management Div.

### 3. Advance preparation (3/3)


Attention: When you install the software to an Offline PC

To download the software installer and to activate the license, you need an Online PC.

To transfer the software installer and activation file from the Online PC to the Offline PC use USB memory or your local network.


#### Installing software to an Offline PC

##### Installing software to online PC



## 4. Steps for software activation (Online) (1/2)


- Before conducting software license activation, please first install the software.
- Activation is done using the activation software that is installed with the software.
- Steps for activation on the Online PC is explained at [[II 3.1 Activation on the Online PC](#)].



- Above shows the steps when installing the software to the computer that can access the Internet. When installing the software to a computer that cannot access the Internet, refer to the next page.

## 4. Steps for software activation (Offline) (2/2)

- When installing the software on an offline PC, please do the following.
  - Do not install the downloaded software to the Online PC!
  - Copy the software to the Offline PC.
- The steps to activate on Offline PC is explained in [[II 3.2 Activate on the Offline PC](#)].




## II . Steps of Operation

This part explains the steps of operation of software delivery server and license server with an example based on a FANUC CNC GUIDE.

1. Download the software installer
2. Install the software
3. Steps to activate
  - 3.1. For online PC
  - 3.2. For offline PC

# 1. Download the software installer / Overview

This chapter explains steps of download a software installer like ISO image file or ZIP file from the software delivery server (FANUC America Customer Portal).



## [Things to prepare]

### (1) Account at FANUC Customer portal

A valid account at FANUC Customer portal is necessary to download the software. If you have no account, please register at FANUC Customer portal (<https://myportal.fanucamerica.com/>).

### (2) Online PC

This Online PC is used to download the software installer by a web browser, so it does not need to be the same as the computer that runs the software.

# 1. Download the software installer / Notification email

For example: Contents of a "Order Acknowledgement"

**FANUC**

**Order Acknowledgement**

**Ship To:** FANUC AMERICA CORP CHICAGO  
1800 LAKEWOOD BLVD  
HOFFMAN ESTATES, IL, 60192, US

**Bill To :** FANUC AMERICA CORP CHICAGO  
1800 LAKEWOOD BLVD  
HOFFMAN ESTATES, IL, 60192, US

Line No.	Item	UOM	Quantity	Customer Part #	List Price	Discount	Amount	Scheduled Ship Date
2	A08B-9510-J702#ZZ99 FANUC MT-LINKi (Software license, 20 machines) FANUC CNC GUIDE (Software license 1 user)	EA	1		4536.00		4536.00	NA
3	A08B-9010- FANUC CNC user) FANUC CNC		1		1134.00		1134.00	NA

**Download URL**  
<https://portal.fanucamerica.com>

**LINK TO DOWNLOAD SOFTWARE**

**INSTRUCTION MANUAL FOR DOWNLOAD AND LICENSE ACTIVATION:**  
[https://www.fanucamerica.com/documents/pc-software-download/ManualForCustomer\\_DownloadAndActivation\\_A-45268-00001EN\\_FAC\\_V3.pdf](https://www.fanucamerica.com/documents/pc-software-download/ManualForCustomer_DownloadAndActivation_A-45268-00001EN_FAC_V3.pdf)

**Software Download Conditions:**  
<https://www.fanucamerica.com/documents/nc-software-download/Software%20Download%20Conditions.pdf>

\*Software Download only in North America\*

Thank you for your order. Please reference order number 1212121564 with any future communication FANUC America provides a 1year warranty on all spare parts from the point of sale. FANUC America must be notified within the 1year warranty claim. Failure to contact FANUC America within 1 year on a warranty claim will result loss of the warranty claim. Warranty will be approved by FANUC America before warranty credit is issued.

Goods Amount	:	5670.00	Total:	5670.00
Discount Amount	:		Currency:	USD
Tax	:	30.00		
Sales Rep	:	Brito, Mr. Robert		

# 1. Download the software installer / Step1 (1/2)


Step1. Access to the software delivery server (FANUC America Customer Portal)

- Login to FANUC America CNC Customer Portal (<https://myportal.fanucamerica.com/>).
- Navigate to “PC Software Downloads”



# 1. Download the software installer / Step1 (2/2)

## (c) Agree the terms and conditions



Software Download Terms & Conditions

I agree to the [Software Download Terms & Conditions](#)

**Agree** **Disagree**

Click the link to display the Download condition

Click the “Agree” button to display download page

**FANUC**

Download Conditions

The above PC software is a product provided on condition that the following items are observed.

By downloading this product, FANUC will assume that you have agreed to the following matters:

- The above PC software is intended to be used by residents of the country in which it is downloaded. Download only from a server in which you are located.
- It is necessary to carry out procedures based on the foreign trade law and other applicable laws and regulations when you export this software. For example:
  - When providing downloaded PC software outside the country in which you downloaded it.
  - When providing to non-residents in the country in which you downloaded it even if it is used in that country.
- It is the customer's responsibility to prepare the Internet environment and devices required for downloading the above PC software, activating the software license without data destruction or leakage, malware, hacking, or other security risks, and following all of the terms of the applicable software license agreement.
- The customer must prohibit the use of the above PC software for the development, manufacture, use and storage of weapons of mass destruction.
- FANUC shall not be liable for any damages caused by the customer's failure to comply with 1 to 4 above.


If you have any questions, please contact our sales people.

If you do not want to accept this email, we apologize for the inconvenience, but thank you for your cooperation in the following:
 

- Please do not access the download URL.
- Without copying or disclosing this e-mail to the outside, write on the e-mail "I am returning this e-mail because I do not believe I am supposed to receive it." Please attach it and return it.
- Please delete this email.

**FANUC** CLOUD SYSTEMS | DRIVE SYSTEMS | LASER SYSTEMS | ENGINEERED SOLUTIONS  
TRAINING | PARTS | OPTIONS | CONTRACTS | SERVICE | REPAIR

## (d) Download the software installer



Instructions

Please click on the hyperlink of the software item Order Number to register the product.

Click the button to start download software

Order Number	Order Date	Item Name	Item Description	License Ticket	Download
<a href="#">1212121564</a>	11-Apr-2022	A08B-9510-J702#ZZ99	FANUC MT-LINKi (Software license, 20 machines)	99999-99999-99999-99999-99999	
<a href="#">1212121564</a>	11-Apr-2022	A08B-9010-J790#ZZ99	FANUC CNC GUIDE(Software license, 1 user)	99999-99999-99999-99999-99999	

# 1. Download the software installer / Step2

## Step2. Check the download file.

When the download is complete, open the download folder and confirm the file exists. In addition, the following image's software installer extension is "iso", but depending on the software, it may be a "zip" file or some other format.




## Attention

When you transfer software to other computer, this software installer is needed, so please keep it.

## 2. Install the software / Online PC

This chapter explains steps for installing the software.


### 2.1 Steps for installing the software to online PC.



For installing the software, refer to each software manual.

## 2. Install the software / Offline PC

### 2.2 Steps of installing the software to an Offline PC



#### Step1. Transfer the software installer

Do not install the software to Online PC!

Transfer the software installer to the Offline PC.

#### Step2. Installing the software

For installing the software, refer to each software manual.

### 3. Steps to activate


This chapter explains the steps to activate the software at each type of computer, because the steps to activate are different between Online PC and Offline PC.

[3.1 Activation on the online PC](#)

[3.2 Activation on the offline PC](#)

## 3.1 Activation on the Online PC / Overview

The software installed on the online PC will be activated as follows:



[Thing to prepare]

### (1) Order Acknowledgment from FANUC

This includes license server URL and license tickets.

License tickets are different for every software, so please check the specification number on the order acknowledgment when purchasing multiple types of software. You can also check that on the member page of the FANUC America Customer Portal site.


### (2) Online PC that is installed the software

Activate the software by accessing license server.

## 3.1 Activation on the Online PC / Step1 (1/2)

### Step1. Enter the ticket on the license server

- Access to FANUC America Customer CNC Portal and navigate to the PC Software Download page, by Google Chrome browser.
- Click the link of the software item Order Number to access the license server.




The screenshot shows the FANUC PC Software Downloads page. At the top, there is a yellow header bar with the FANUC logo, navigation links for 'After Market' and 'Support', and a phone icon for '888-FANUC-US'. Below the header, the page title is 'PC Software Downloads'. A 'License ticket' callout box points to the 'License Ticket' column in a table. The table has columns for 'Order Number', 'Order Date', 'Item Name', 'Item Description', 'License Ticket' (which is highlighted with a red box), and 'Download'. The 'Order Number' column contains the value '1212121525', which is also highlighted with a red box. The 'License Ticket' column is currently empty and also highlighted with a red box. The 'Download' column contains a download icon.

Order Number	Order Date	Item Name	Item Description	License Ticket	Download
1212121525	15-Mar-2022	A08B-9010-J790#ZZ99	FANUC CNC GUIDE(Software license, 1 user)		

## 3.1 Activation on the Online PC / Step1 (2/2)


(c) Enter the License ticket on the software download site to the following [Ticket] filed, and click [Next].



## 3.1 Activation on the Online PC / Step2 (1/4)

### Step2. Activation

- (a) The software that you purchased is displayed.  
Check the software name and click [Activate Licenses].




The screenshot shows a web browser window with the title 'WebDepot'. The URL in the address bar is 'lc.codemeter.com/91943/depot/overview.php'. The page is titled 'DUCNET' and features a navigation bar with 'Home', 'My Licenses' (which is underlined, indicating it is the active tab), and 'Auto Update'. On the right, there is a language selection box set to 'English' with a UK flag. The main content area is titled 'My Licenses' and contains a table with the following data:

Name	Activated On	CmContainer	Status
FANUC CNC GUIDE (Software License 1 user)	-		Available

At the bottom of the table, there is a blue button with the text 'Activate Licenses' enclosed in a red rectangular box.

## 3.1 Activation on the Online PC / Step2 (2/4)

- (b) Select the [Get CmContainer automatically], and click [Activate Selected Licenses Now].




The screenshot shows a web browser window titled 'WebDepot' with the URL 'lc.codemeter.com/91913/depot/get.php'. The page is for 'DUCNET' and is in English. The 'My Licenses' tab is selected. The 'Available Licenses' section shows a list with one item: 'FANUC CNC GUIDE (Software License 1 user)'. The 'Status' column for this item is 'Available'. Below the list, there is a 'Select CmContainer' section with a dropdown menu set to 'Get CmContainer automatically' and a radio button next to it. A large red box highlights this dropdown. Below the dropdown is a red-bordered button labeled 'Activate Selected Licenses Now'. A smaller red box highlights this button. At the bottom of the page, there is a link to 'My Licenses' and a copyright notice: '© 2021 DUCNET'.

## 3.1 Activation on the Online PC / Step2 (3/4)

(c) First, the window on left side is displayed.


Please wait until <License transfer completer successfully> window on right side is displayed.

(d) Click [OK] on the right side window.



### 3.1 Activation on the Online PC / Step2 (4/4), Step3

(e) Check [Status] of purchased software is <Activated>.



The screenshot shows a web browser window for 'DUCNET' with the URL 'lc.codemeter.com/91945/depot/overview.php'. The page is titled 'My Licenses' and displays a table of software licenses. The table has columns: Name, Activated On, CmContainer, and Status. A single row is shown: 'FANUC CNC GUIDE (Software License 1 user)' with activation date '2021-12-06 13:08:56', container '100-2401974897 (DESKTOP-FBL001P)', and status 'Activated'. The 'Status' column is highlighted with a red box. A blue cloud icon is overlaid on the top left of the browser window.

Name	Activated On	CmContainer	Status
FANUC CNC GUIDE (Software License 1 user)	2021-12-06 13:08:56	100-2401974897 (DESKTOP-FBL001P)	Activated


Step3. Check that the software is working.

For how to use the software, refer to each manual.

## 3.2 Activation on the Offline PC / Advance preparation

The software installed on the Offline PC will be activated as follows:

### Overview of this steps



### [Thing to prepare]

#### (1) Order Acknowledgment from FANUC

This includes license server URL and license tickets.

License tickets are different for every software, so please check the specification number on the order acknowledgment when purchasing multiple types of software. You can also check that on the member page of the FANUC America Customer Portal site.

#### (2) Online PC that can access to the license server

Do not install the software on the Online PC!

Install the software to the Offline PC.

#### (3) Offline PC where the software is installed


Run the activation software. It is installed with the software.

## 3.2 Activation on the Offline PC / Steps

This chapter explains the following steps from 1 to 14.

(When click each step, move to its page. And when click  Back to list page, back to this page.)


### Overview of this steps



## 3.2 Activation on the Offline PC / Step1 (1/3)

### Step1. Enter the ticket on the license server

- Access to FANUC America Customer CNC Portal and navigate to the PC Software Download page, by Google Chrome browser.
- Click the link of the software item Order Number to access the license server.




The screenshot shows the FANUC PC Software Downloads page. At the top, there is a yellow header bar with the FANUC logo, navigation links for 'After Market' and 'Support', and a phone icon with the number '888-FANUC-US'. Below the header, the page title is 'PC Software Downloads'. A 'License ticket' callout box points to the 'License Ticket' column in a table. The table has columns for 'Order Number', 'Order Date', 'Item Name', 'Item Description', 'License Ticket' (which is highlighted with a red box), and 'Download'. The 'Order Number' column contains the value '1212121525', which is also highlighted with a red box. The 'Item Description' column shows 'FANUC CNC GUIDE(Software license, 1 user)'. The 'Download' column contains a download icon.

Order Number	Order Date	Item Name	Item Description	License Ticket	Download
1212121525	15-Mar-2022	A08B-9010-J790#ZZ99	FANUC CNC GUIDE(Software license, 1 user)		

## 3.2 Activation on the Offline PC / Step1 (2/3)


- (c) Enter the License ticket on the email to the following [Ticket] filed and click [Next].



The screenshot shows a web browser window titled "WebDepot" with the URL "lc.codemeter.com/91943/depot/". The page is titled "Welcome to CodeMeter License Central WebDepot". It contains a message: "Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your CmContainer using this WebDepot. Please enter your ticket and click "Next". Below this is a "Ticket:" input field, which is highlighted with a red border. At the bottom is a "Next" button, also highlighted with a red border. The page footer says "© 2021 DUCNET".

## 3.2 Activation on the Offline PC / Step1 (3/3)

- (d) The software that you purchased is displayed.  
Check the software name and click [Activate Licenses].



The screenshot shows a web browser window with the title 'WebDepot'. The URL in the address bar is 'lc.codemeter.com/91943/depot/overview.php'. The page is titled 'DUCNET' and features a navigation bar with 'Home', 'My Licenses' (which is underlined, indicating it is the active tab), and 'Auto Update'. On the right, there is a language selection box set to 'English' with a UK flag. The main content area is titled 'My Licenses' and contains a table with the following data:


Name	Activated On	CmContainer	Status
FANUC CNC GUIDE (Software License 1 user)	-		Available

At the bottom of the table, there is a blue button with the text 'Activate Licenses'.

## 3.2 Activation on the offline PC / Step2 (1/3)

Step2. download template file

(a) Click <File based license transfer> on the following screen.




The screenshot shows a web browser window titled 'WebDepot' with the URL 'lc.codemeter.com/91913/depot/get.php'. The page is for 'DUCNET' and displays 'Available Licenses'. A callout bubble with a blue arrow points to the 'File based license transfer' button, which is highlighted with a red box. The page includes a navigation bar with 'Home', 'My Licenses' (which is selected), and 'Auto Update'. It also shows a language selection for 'English' and a 'Select CmContainer' dropdown with the option 'Get CmContainer automatically'. The main content area shows a table of available licenses, with one entry for 'FANUC CNC GUIDE (Software License 1 user)' marked with a checkmark. At the bottom, there are buttons for 'Activate Selected Licenses Now' and 'File based license transfer'.

## 3.2 Activation on the Offline PC / Step2 (2/3)

Step2. download template file

(a) Click <How it works> on the following screen.

 Back to list page

Available Licenses

Upload Request      Download Update      Upload Receipt

To activate your licenses via file transfer - First step "Upload Request":

If you have activated licenses from this ticket already, you can transfer additional licenses into the same CmContainer(s). If you want to use another CmContainer, you need a license request file of this new CmContainer.


1. Select an already used CmContainer or create a license request file with **Firm Code 6001405** for the CmContainer where you want to transfer the licenses to. This file can for example be created with CodeMeter Control Center [How it works +](#)
2. Select the licenses you want to activate.
3. Select the created license request file.
4. Click "Continue".

Name	Activated On	CmContainer	Status
FANUC CNC GUIDE (Software License 1 user)	-		Available

## 3.2 Activation on the Offline PC / Step2 (3/3)




- (b) Click <Download template now> on the following screen.  
Download template file (\*) every time because it is different every ticket.




(\*) See the next page for more information of template file.

## 3.2 Activation on the Offline PC / Step3

(c) After downloading the template file, transfer it to the Offline PC.



Step3. Transfer the template file from the Online PC to the Offline PC.



(\*) What is the template file?

- Activation has a purpose to prevent illegal duplication of use by identifying the computer that use the software. So, the license server need to acquire the computer that runs the software.
- The template file is "Model" of [License request file] that will be created on the offline PC in Step7, and has the configuration of the Offline PC.

## 3.2 Activation on the Offline PC / Step4 (1/2)


Step4. Import the template file to the offline PC



(a) Start the Control Center that is used for import.


Start the <CodeMeter Control Center> in the <CodeMeter> folder from Windows start menu.

When it is not displayed, the downloaded software from the software delivery server may be not installed.




## 3.2 Activation on the Offline PC / Step4 (2/2)


- (b) Select the <Import License> in <File> on the Control Center to import the template file.
- (c) Change [All Files (\*)] when dialog is displayed. And select the template file that was transferred in Step3 and click the <Import>.
- (d) [Empty license container] will be imported like a right image.  
 Make a memo of the displayed serial number. It will be needed later (Step10 and Step11).



(b)



(c)




(d)

## 3.2 Activation on the Offline PC / Step5 (1/2)

Step5. Create the license request file

 Back to list page


- (a) Start the CmFAS assistant by clicking <License Update> on the Control Center.  
Click <Next>.




## 3.2 Activation on the Offline PC / Step5 (2/2), Step6

- (b) Select <Create license request> on the CmFAS assistant and click <Next>. Set the destination path and click <Commit>. When [The license request file has been successfully created.] dialog is displayed, click <Finish>.

 Back to list page




### Step6. Transfer the license request file to the online PC



## 3.2 Activation on the Offline PC / Step7 (1/2)

Step7. Upload the license request file

(a) Click <Choose File>.

 Back to list page

Available Licenses

Upload Request      Download Update      Upload Receipt

To activate your licenses via file transfer - First step "Upload Request":

If you have activated licenses from this ticket already, you can transfer additional licenses into the same CmContainer(s). If you want to use another CmContainer, you need a license request file of this new CmContainer.

1. Select an already used CmContainer or create a license request file with **Firm Code 6001405** for the CmContainer where you want to transfer the licenses to. This file can for example be created with CodeMeter Control Center. [How it works](#)
2. Select the licenses you want to activate.
3. Select the created license request file.
4. Click "Continue".

Name	Activated On	CmContainer	Status
<input checked="" type="checkbox"/> FANUC CNC GUIDE (Software License 1 user)	-		Available


Select an already used CmContainer  
No CmContainer found! ▾

or

Pick a license request file (\*.WibuCmRaC) of another CmContainer  
 No file chosen

## 3.2 Activation on the Offline PC / Step7 (2/2)

- (b) When a dialog for selecting file open,  
click the license request file and click <Open>.
- (c) After the dialog closes, click <Start Activation Now>.





## 3.2 Activation on the Offline PC / Step8 (1/2)

### Step8. Download the license update file



- (a) After uploading the license request file to the license server, above of screen change from [Upload Request] to [Download Update].  
Click <Download License Upload File Now> to download the license update file.



**DUCNET**

Home My Licenses Auto Update

English

Download License Update File

Upload Request ✓ Download Update Upload Receipt


To transfer your licenses via file - Second step "Download Update":

1. Click "Download License Update File Now" and save the file on your computer.
2. Import this license update file to the CmContainer with **Serial 130-892454747**. This file can for example be imported with CodeMeter Control Center. [How it works](#) +
3. After you have successfully transferred the license update file to the CmContainer, click "Next" to confirm the license transfer.


Download License Update File Now Next Direct license transfer

## 3.2 Activation on the Offline PC / Step8 (2/2), Step9

- (b) After downloading the license update file, click <Show in folder> to check it exist. This file is transferred to the Offline PC.



Step9. Transfer the license update file from the Online PC to the Offline PC.




## 3.2 Activation on the Offline PC / Step10 (1/3)

### Step10. Import the license update file (Activation)






- Start the Control Center and select the serial number (memo in Step4).
- Click <License Update> on the Control Center to start the CmFAS assistant.
- After starting CmFAS assistant, click <Next>.




## 3.2 Activation on the Offline PC / Step10 (2/3)

- (d) Select <Import license update> on the CmFAS and click <Next>.
- (e) Set the license update file that was transferred from the online PC and click <Commit>.
- (f) After [Import Update successful.] is displayed, click <OK>.





## 3.2 Activation on the Offline PC / Step10 (3/3)

- (g) After back to the CmFAS assistant, click <Finish>.



- (h) After return to the Control Center, check that [License activated] is displayed as Status.




## 3.2 Activation on the Offline PC / Step11 (1/3)

### Step11. Create receipt file



- Start the Control Center and select the serial number (memo in Step4).
- Click <License Update> on the Control Center to start the CmFAS assistant.
- After starting CmFAS assistant, click <Next>.





## 3.2 Activation on the Offline PC / Step11 (2/3)

(d) Select <Create receipt> on the CmFAS assistant and click <Next>.


(e) A receipt file is a file that is created on this screen newly.

Click <Commit> because [Please select the file name] field will be displayed same name as the license request file in Step6.



 Back to list page


## 3.2 Activation on the Offline PC / Step11 (3/3), Step12

- (f) After displaying [The license receipt file has been successfully created], click <Finish>.




Step12. Transfer the receipt file to the online PC



## 3.2 Activation on the Offline PC / Step13 (1/5)

Step13. Upload the receipt file

(a) Click <Next>.

 Back to list page

The screenshot shows the DUCNET software interface. At the top, there is a navigation bar with 'Home', 'My Licenses', and 'Auto Update' buttons. On the right, there is a language selection box set to 'English' with a UK flag. Below the navigation bar, the title 'Download License Update File' is displayed. A progress bar at the top indicates the steps: 'Upload Request ✓' (gray), 'Download Update' (blue, highlighted with a red box), and 'Upload Receipt' (gray). A text box below the progress bar contains instructions: 'To transfer your licenses via file - Second step "Download Update":' followed by three numbered steps. At the bottom, there are three buttons: 'Download License Update File Now' (blue), 'Next' (blue, highlighted with a red box), and 'Direct license transfer' (green).

To transfer your licenses via file - Second step "Download Update":

1. Click "Download License Update File Now" and save the file on your computer.
2. Import this license update file to the CmContainer with **Serial 130-892454747**. This file can for example be imported with CodeMeter Control Center. [How it works](#) +
3. After you have successfully transferred the license update file to the CmContainer, click "Next" to confirm the license transfer.


Download License Update File Now

Next

Direct license transfer


## 3.2 Activation on the Offline PC / Step13 (3/5)

- (b) Check that [Upload Receipt] is enabled and the serial number (memo in Step4) is displayed.  
(c) Click <Choose File>.



## 3.2 Activation on the Offline PC / Step13 (4/5)

- (d) After opening a dialog for file select, click the receipt file and click <Open>.  
(e) After closing the dialog, click <Upload Receipt Now>.




## 3.2 Activation on the Offline PC / Step13 (5/5), 14

(f) [License Transfer Successfully Completed] is displayed. Click [OK].



(g) Check both the serial number (memo in Step4 on the [CmContainer] is displayed and [Activated] in the [Status] is displayed.



The screenshot shows two browser windows. The left window displays a 'License Transfer Successfully Completed' message with an 'OK' button, both of which are highlighted with red boxes. The right window shows a 'My Licenses' table with one row of data. The 'CmContainer' column shows the serial number '130-892454747 (DESKTOP-FBL001P)' and the 'Status' column shows 'Activated', both of which are also highlighted with red boxes. A blue callout bubble with an arrow points to the 'OK' button in the left window.

Name	Activated On	CmContainer	Status
FANUC CNC GUIDE (Software License: 1 user)	2021-12-06 18:10:27	130-892454747 (DESKTOP-FBL001P)	Activated

Step14. Check to run the software.

For operating the software, refer to each software manual.

# Notice

## Attention about the computer that activated the software.

If the configuration (hardware and OS and more) of the computer is changed significantly, the software may be unavailable. When the software is unavailable, please contact our Aftermarket Support team at [AfterMarketSupport@fanucamerica.com](mailto:AfterMarketSupport@fanucamerica.com)

## Trademarks and Registered Trademarks

- Microsoft, Windows are trademarks or registered trademarks of Microsoft Corporation in the U.S. and other countries.
- Google and Chrome are registered trademarks of Google LLC.
- CodeMeter is registered trademarks of WIBU-SYSTEMS AG in the Germany.